

MPP200 User's Manual



©2011 Visionary Solutions, Inc. All rights reserved.

Please visit the support section of our website at www.vsicam.com for manuals, other documentation, and software downloads.

Visionary Solutions, Inc.
2060 Alameda Padre Serra
Suite 100
Santa Barbara, CA 93103
T:805-566-5811
F:805-566-5813
www.vsicam.com

May 17, 2011
Revision 1.0.4

About This Guide

VSI recommends that you download the most recent version of this Manual from www.vsicam.com.

Limited Liability

In no event shall Visionary Solutions, Inc. be liable, whether in contract, tort, or otherwise, to OEM or Customers for (a) any damages resulting from loss of use, data or profits howsoever arising hereunder in relation to or in connection with Visionary Solutions, Inc. Software, (b) any special, indirect, incidental or consequential damages, even if Visionary Solutions, Inc. has been advised of the possibility thereof. Visionary Solutions, Inc.'s total liability in contract, tort or otherwise arising out of, in connection with or in relation to the Software or otherwise under this Agreement shall be limited to the amount paid to Visionary Solutions, Inc. or and authorized Visionary Solutions, Inc. reseller for the Visionary Solutions, Inc. Software or Hardware for a Customer in the 12 month period immediately preceding the event which has given rise to the liability.

The contents of this document are subject to revision without notice due to continued progress in methodology, design, and manufacturing. Visionary Solutions, Inc. shall have no liability for any error or damages of any kind resulting from the use of this document.

Trademark Acknowledgements

All trademarks or registered trademarks are properties of their respective owners.

Visionary Solutions, Inc., Limited 12-Month MPP200 Warranty

We appreciate your purchase of this Visionary Solutions, Inc. product. We feel confident that in normal use it will provide years of satisfactory performance.

Visionary Solutions, Inc. warrants to the original user that the video equipment supplied by us will be free of defects in materials and workmanship for a period of twelve (12) months from the date of purchase from Visionary Solutions, Inc. or an authorized reseller of Visionary Solutions, Inc. Visionary Solutions, Inc.'s obligation under this warranty shall be to the repair including any necessary parts and the cost of labor connected therewith, or at its option, the exchange or the refund of the purchase price, of any video equipment that is determined by us to have a manufacturing defect within the warranty period.

Replacement parts furnished in connection with this warranty shall be warranted for a period equal to the unexpired portion of the original equipment warranty.

Warranty Exclusions

This warranty does not apply to repairs or replacements necessitated by any cause beyond the control of Visionary Solutions, Inc., including, but not limited to, acts of nature, improper installation, misuse, lack of proper maintenance, accident, voltage fluctuations, and unauthorized repairs or modifications.

This warranty becomes void in the event serial numbers are altered, defaced, or removed.

Visionary Solutions, Inc. reserves the right to make changes in the design, or make additions to, or improvements upon, this product without incurring obligations to install the same on products previously manufactured.

The foregoing warranty is in lieu of all other warranties, expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Visionary Solutions, Inc. neither assumes nor authorizes any person to assume for it any other obligations or liabilities in connection with the sale of its products. In no event shall Visionary Solutions, Inc. or its authorized resellers be liable for special or consequential damages arising from the use of its products, or any delay in the performance of this warranty due to causes beyond its control.

IN THE U.S.A., SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS AND/OR THE EXCLUSION OR LIMITATION OF CONSEQUENTIAL DAMAGES, SO THE PREVIOUSLY STATED LIMITATIONS ON IMPLIED WARRANTY AND CONSEQUENTIAL DAMAGES MAY NOT APPLY TO YOU.

Customer Obligations

The original, dated, bill of sale should be retained as proof of purchase and must be presented to the Visionary Solutions, Inc. or a Visionary Solutions, Inc. Authorized Service Center when this equipment is to be serviced under the provisions of this warranty.

The cost of transportation to and from the Authorized Service Center is the responsibility of the user.

How to Obtain Warranty Service

Should this equipment require warranty service you may obtain specific information on how to obtain this service by directly contacting Visionary Solutions, Inc., or the reseller who sold you this equipment.


The MPP200 User's Manual

1.1 The MPP200

The Media Processing Platform (MPP) 200 is a high density, blade chassis used in VSI IPTV applications. It can be rack mounted in a 1U space or used as a stand alone.

Slots 1 and 2 on the chassis can be filled with any VSI blade product.

1.1.1 MPP200 Front Panel Slots



1.1.2 MPP200 Rear Panel



Status 1 – Copies the status LED pattern of the blade inserted into Slot 1. For more information about the blade, refer to the VSI User's Manual for that blade.

Video 1 – Copies the video LED pattern of the blade inserted into Slot 1. For more information about the blade, refer to the VSI User's Manual for that blade.

Power – The Power LED illuminates green when power is supplied to the chassis.

Status 2 – Copies the status LED pattern of the blade inserted into Slot 2. For more information about the blade, refer to the VSI User's Manual for that blade.

Video 2 – Copies the video LED pattern of the blade inserted into Slot 2. For more information about the blade, refer to the VSI User's Manual for that blade.

1.2 Rack Mounting the MPP200

Warning: Before installing the MPP200, be sure to read the safety and equipment information contained in this chapter.

Caution: Use proper electrostatic discharge (ESD) precautions when installing or removing the MPP200 to avoid damaging the unit's circuitry.

The MPP200 is designed to be rack mountable. It is 5.7 inches wide and utilizes 1U of rack space when mounted. Refer to the sections that follow for information on installing blades and blanking panels.

In order to install the MPP200 on a rack, you will need an MPP200 Rack Mount Kit and a Phillips screwdriver. The kit includes 2 small brackets, 1 medium length bracket, 1 long bracket, and 10 screws. The MPP200 Rack Mount Kit can mount one or two MPP200s in a 1U space, and can be purchased online at www.vsicam.com.

1. Locate and remove two pairs of screws from the chassis, depending upon the desired final position of the chassis in the rack (front or back).

For example, to mount the chassis in the rack with the front facing out, remove the pairs of screws (left and right) closest to the front of the chassis, leaving the middle and back screws in place.

2. **Install one MPP200 chassis:** you will need one small bracket, the long bracket, and four screws from the MPP200 Rack Mount Kit.
 - a. On the side of the chassis that is to be next to the rack sidewall, attach one of the small brackets, using the smaller holes on the bracket and the empty screw holes on the chassis. Make sure that the larger holes on the bracket are flush with the face of the chassis.
 - b. Attach the long bracket to the other side of chassis so that the longest face of the bracket is flush with the chassis (front or back depending on the mounting position).
 3. **Install two MPP200 chassis:** you will need two small brackets, the medium bracket, and eight screws from the MPP200 Rack Mount Kit.
 - a. Attach a small bracket to each chassis so that the brackets are attached on opposite sides (e.g., so that one chassis has a bracket on the left side and the other has a bracket on the right side), using the smaller holes on the bracket and the empty screw holes on the chassis. Make sure that the larger holes on the brackets are flush with the face of the chassis.
-

- b. Attach the medium bracket between the two chassis so that the longest bracket face is flush with the face of the chassis (front or back depending on the mounting position).
4. Install your blades and or blanking panels, see Section 1.1.2.
5. Connect the power cable to the rear of the unit(s).
6. Lift the now populated chassis and bracket assembly into the rack at the desired level, and attach with rack screws (not provided).

1.3 Hardware Inventory

1. AC power cord.
2. DC power supply.
3. Four rubber feet.
4. RS-232 console cable.

1.4 Blade Installation and Removal

Note: *It is important that the module be properly aligned with the slot guides before it is inserted into the appropriate slot on the chassis. It is recommended that the user's line of sight be level with the middle of the backplane in order to see both slot guides clearly.*

Install a VSI blade into the chassis as follows:

Caution: Use proper ESD precautions when installing or removing a VSI blade to avoid damaging the unit's circuitry.

1. Slide the blade, open end first, into the desired slot on the chassis until it plugs into the connector located on the backplane at the rear of the unit.
2. To insure that the blade is properly seated in the chassis and mated to the rear connectors, push firmly on the blade's front panel. **Ensure that the front panel face is flush with the chassis ends and sides.** Note the red and black handle on the blade does not mount or lock to anything on the MPP200 chassis.
3. Tighten the captive thumb screw located at the top of the blade to provide a more secure mounting.
4. If desired, an additional Phillips screw can be installed through the handle.
5. The Status LED will blink once a second when the blade is properly installed, powered, and operational.

To remove a VSI blade:

1. Loosen the mounting screw at the top of the blade.
2. If installed, loosen the additional Phillips screw in the ejector handle
3. To pull the blade out of its slot and away from the chassis, pull on the mounting screw at the top of the blade and on the handle at the bottom.

1.5 Installing Blanking Panels

After all blade options have been installed, all empty slots must be populated with blanking panels. Install blanking panels as follows:

Warning: Failure to populate empty slots with blanking panels will negatively effect EMC radiation and immunity.

Note: *Blanking panels are used to cover each of the empty blade slots.*


1. Place the blanking panel onto the face of the MPP200.
2. Tighten the two captive screws on the front of the blanking panel.

1.6 MPP200 Safety and Compliance

Unit Ratings:

 **Caution:** 5Vdc, 4A

Power Supply Rating:

 **Caution:** 100-250V~, 50-60 Hz, 1.0A

Fuse Rating:

No user accessible fuse.

Safety Approvals:

UL Listed I.T.E. E257717